







POLARYS a polarized bolometer camera


Vincent Revéret et al




Unveiling the role of magnetic fields in filaments




Plausible model of the B field in a SF filament



Planck resolution



B-field lines inferred at 350 & 1200 μm at ArTéMiS/POLARIS resolution



➤ Different wavelengths probe different depths within the filament


(for a model filament at $d = 400$ pc)

➔ Needs for a high sensitivity polarimeter camera in the submm

Our starting point : Herschel / PACS Silicon Resistive Bolometers in the 2000's

The goal : large format high sensitivity detectors in the 50 – 200 μm range.

CEA's choice : 16x16 Silicon array of bolometers working at 300 mK




- « All Silicon » design
- **Very High impedance (~ GOhm)**

$$R = R_0 \exp \left(\sqrt{\frac{T_0}{T}} \right) \exp \left(-\frac{qL(T)E}{kT} \right)$$

- **Very High Response**
-> $2 \cdot 10^{10} \text{V/W}$


- **Cryogenic Multiplexing (MOS) : 16 to 1**

- **NEP ~ $2 \cdot 10^{-16} \text{W}/\sqrt{\text{Hz}}$ at 300 mK**



PACS Photometer (2009 – 2012)

- 2560 pixels, 3 bands (70, 100, 160 μm)
- 30% of observing time, most used instrument
- (40 % if parallel mode included)



Horsehead Nebula (André et al)





Cygnus X


Herschel PACS & SPIRE

Credits: ESA/PACS/SPIRE/Martin Hennemann & Frédérique Motte

ArTéMiS on APEX : A Dual Band camera (350 & 450 μm) since 2013, still operating




ArTéMiS 350 μm focal plane




ArTéMiS 450 μm

- Complementary to Herschel Data at 350 μm (extended emission + spatial resolution)
- **Observing Run in Sept. 2024**
- **Another Observation run in July/August this year**





Number of operational pixels	2400
Spatial Resolution 350 μm 450 μm	8'' 10.5''
FOV (350 μm)	4,7 x 2,3 arcmin ²




Column density map of the cloud SDC348
(M. Mattern, A&A 2024)

ArTéMiS - évolution



RCW106 CAFFEINE N_2 map overlaid on VLTST optical image (2024)




- 1765 hrs observed between 2013 and 2022,
- 56 projects → 5 Chile, 25 ESO, 26 OSO
- 2019 to 2022 → 1250h,
- 29 publications since 2008 and 19 since 2013

APEX/ArTéMiS as a « pathfinder » for higher-resolution studies of cloud/filament structure with ALMA and JWST


- ArTéMiS bridges the gap in resolution between *Herschel* and ALMA + JWST

ArTéMiS 350 μm image of
NGC 6334 (d $\sim$ 1.5 kpc)




ArTéMiS « first-light » paper
A&A, 592, A54 (2016)

JWST/MIRI 7.7 μm image
→ mid-IR-dark filament




Column density image
derived from JWST absorption




Why Silicon bolometers?

« Si Technology is not (completely) dead...! »


RESOLVE onboard the JAXA-NASA XRISM Mission



Launched in 2023



6x6 Silicon μ -Calorimeters from NASA
Goddard working at ~ 50 mK




(with ESA participation)

Why Silicon bolometers?

Pushing the limits of this technology




B-BOP's polarimetric bolometers

2021



- Silicon is an amazing material : very high thermal resistance can be reached at low temperature => *high sensitivity*
- Si micro-machining enables to design *complex pixel structures to build compact space instruments*
- *No Need of Magn. shielding*

~2000






SPICA


- In 2016, we joined the SPICA mission with the B-BOP Instrument : a 3 bands imaging polarimeter (70, 200 and 350 μm)
- Science Case : Magnetic Field in the ISM

- High Sensitivity Imaging-Polarimetry inside the pixel is a direct application of these possibilities
- Also, « High impedance » is compatible with CMOS classical electronics that works at 50 mK (EU CESAR project).


The BBOP detectors




The BBOP detectors





VIEW angle @ 45°





The SPICA BBOP test arrays (for the 100 μm band)






« ECLIPSE » : the 50 mK readout electronics

256 pixels with 6 readout units in each pixel=>1536 readout units

CMOS AMS 350nm, 300 PADs. 50-100 mK, $1\mu\text{W}$, 1.7 cm^2




With this Wheatstone bridge circuit, for each pixel we get :

- **Differential polarization unbalance between H and V signals**
- **Differential amplitude signal**

The ADC's are optimized to adapt to the **very different dynamic ranges**.

Testing the Arrays


Extreme challenge : the optical background is $\sim$ fW/pixel




30K Optical source,
using concentric
emitting rings

- Main parameters have been measured at cold temperature
- Very good results (**NEP Goal for SPICA/BBOP reached**)
- Challenges : thermal issues (readout currents), full MUX demonstration


Pixel Absorption
> 90% at 100 μ m




(Cryogenic FTS)



Polarimetry
Cross pol $\sim$ 0.1%





Noise / Sensitivity
NEP = $1.4 \cdot 10^{-18}$ W/Hz $^{1/2}$





B-BOP, the instrument on SPICA

« **Simple & Compact Design** » : No moving part, no rotating plate (except for calibrator unit), no **Magn. Shield**.

Big Advantage on the System Point of View




- The Focal Plane Assembly contains 6 bolometer modules (1344 bolometers in total).
- It is a « 3 levels » system : 2K housing, 300mK and 50mK stage (structures suspended by Kevlar wires)



- Mass ~ 25 kg (63 kg including warm electronics)
- Power : 86 W (warm electronics)
- Power dissipation @ 50 mK ~1 μ W

POLARYS in a nutshell

- **Adding Polarimetry to ArTeMiS, at 350 μm**
- 350 μm arrays are being built at CEA-LETI (**funded** by labex FOCUS + internal CEA funds)
- **Re-use the ArTeMiS mechanical structure at maximum**
- Optical study to characterise the instrumental polarization
- Optimizing the cryogenic system (working < 300 mK)
- Readout Electronics to be tested
- **Funding applications in progress (ANR, DIM Origines,...)**
- **On sky at APEX in ...? 2028/2029?**




POLARYS (& BBOP) Polarization Sensitivity


Surface Brightness Sensitivity [MJy.sr⁻¹] of BBOP for polarimetric imaging.

- total surface-brightness level required to detect polarization at 7σ ($p/\sigma=7$)
- 5% fraction polarization
- NEP = 3.10^{-18} WHz^{-1/2}
- Background includes:
 - Zodiacal light, ISM, CIB, CMB at location typical of **low-emission Galactic** regions
 - Telescope
 - Instrument optics (transmission 50%)
 - Atmosphere
- For space : 70 μ m Band : 1024 pixels, 200 μ m Band :


Instrument	Diameter [m]	Telescope Temperature [K]
SPICA	1.8	8
Millimetron	10	45
SALTUS	14	45 & 30
APEX (4096 pixels)	12	270
AtLAST	50	270




Adding (mid-R) Spectroscopy to the Array



(1) A Compact Scanning Fabry-Perot





(2) A Bayer Filter Array




Spectroscopy – Preliminary results ($R \sim 200 / 300$)

Adjustable cryogenic Fabry-Perot made of Si Bragg mirrors



Stationary array of Fabry-Perot made of microstructures Si.



Other opportunities





- CO-PILOT

- *Detection of C+ @ 158 μm*
- *CNES balloon*
- *CEA bolometers, SRON Fabry Perot, PI : IRAP*



- The TALC Deployable Space Telescope


- 20 m diameter annular telescope



Summary



- We push Silicon technology to its limits : high sensitivity & in-pixel functions
- The in-pixel polarimetry enables **very compact and simple instrument** (no moving part) – **Optimization of the system**
- Robust & High TRL : Herschel heritage, PhaseA study for SPICA
- Challenges on RO electronics / Detection layer on thermal aspects , MUX
- Opportunities toward POLARYS, TALC (?), Co-PILOT(?)



Contributors

Saclay DAp Group

C. Delisle
E. Doumayrou
J. Martignac
X-F. Navick
A. Poglitsch (MPE)
V. Revéret
L. Rodriguez
J-L. Sauvageot
T. Tollet

Saclay DEDIP Group

X. Coppolani
X. De la Broise
A. Demonti
S. Dubos
O. Gevin

Grenoble Leti Group

A. Aliane
L. Dussopt
V. Goudon
A. Jouve
H. Kaya

Fundings






Spectroscopy with metamaterials / High Impedance Surfaces

Project HIS350 : Proof of concept

- Very good absorption (room and cold temp.)
- Absorption independant of the dipole angle

Motif élémentaire:

- période $37.5\ \mu\text{m}$
- gap $4.6\ \mu\text{m}$
- via $\varnothing\ 3\ \mu\text{m}$



Idea = Modulation of the spectral response using an external magnetic field and / or « varactors ».

